



**Vertical distance between holes**

	Inch	mm
A	1.5"	38.1
B	3"	76.2
C	2.5"	63.5
D	10"	254
E	5"	127

**Total Door Undersizing**

- Single Square Edge Door – 15/32"
- Single Bevel Edge Door – 1/2"
- Pair of Doors, each leaf, Square Edge Door – 7/16"
- Pair of Doors, each leaf, Bevel Edge Door – 15/32"

Reinforcement recommended for six hole pattern at top and bottom of each leaf of hinge.

**Hole Preparation (40 places)**

**Metal frame:**

Standard self drilling self tapping screws - No drilling required  
 Optional thread forming screws - #13 or 3/16" drill

**Wood frame:**

5/32" drill, 1.5" deep



112HD 83" & 85" Concealed Continuous Hinge Profile Template



**Note:** Dimensions in [ ] are millimeters

Template Number 829221-00(C)

Date: 11-10-11